

t i r e r e p a i r *u s e r g u i d e*

USING A PATCH KIT TO FIX A FLAT

GLUELESS

1. Locate puncture hole in the tube.
2. Clean and roughen the area around the hole with the supplied scuffer
3. Peel off the backing from the patch and apply the patch over the hold while avoiding touching the sticky (glue) side
4. Press and hold the patch firmly for 30 seconds
5. Reinstall tube and inflate

GLUE

1. Locate puncture hole in the tube.
2. Clean and roughen the area around the hole with the supplied scuffer
3. Apply glue and wait approximately 2 minutes or until glue is tacky
4. Press and hold the patch firmly for 30 seconds
5. Reinstall tube and inflate

TIRE BOOT

In the occurrence of a rip, slice, or tear in your tire, this boot can be used as a patch between your tire and tube to help prevent your tube from blowing out of the damaged tire. Simply remove the clear film to expose the glue and place the boot over the rip. Once you've reached your destination, immediately replace your tire with a new one.

For models:

Lever Kit
Metal Kit
Alloy Kit
Smart Kit
Classic Kit