



# PHOTO DOG

## MINI DIGITAL CAMERA BAG



**PERFECTLY SIZED TO FIT YOUR  
DIGITAL CAMERA/CABLE/MEMORY CARD**



**FITS KNOG BAGS WITH 74MM SHOULDER STRAP -**


**/HOT DOG  
/FRANKS DOG  
/PIG DOG  
/BIG DOG  
/DRY DOGS**

**INTERNAL FOAM PADDING**


**WATER-RESISTENT  
WAXED FABRIC BODY**




[www.knog.com.au](http://www.knog.com.au)



Unclip shoulder strap from bag.




Insert bag strap into channel  
on rear of Photo Dog.



Slide Photo Dog along strap  
and reattach strap to bag.



Photo Dog has room for your  
camera and accesories



Secure items inside pouch  
by fastening velcro tab.